

# STEERING

## CONTENTS

	page		page
POWER STEERING .....	1	STEERING COLUMN .....	24
POWER STEERING GEAR .....	10	STEERING LINKAGE .....	20
POWER STEERING PUMP .....	6		

## POWER STEERING

### INDEX

	page		page
<b>DESCRIPTION AND OPERATION</b>		STEERING FLOW AND PRESSURE .....	4
POWER STEERING SYSTEM .....	1		
<b>DIAGNOSIS AND TESTING</b>			
POWER STEERING SYSTEM DIAGNOSIS			
CHARTS .....	2		

### DESCRIPTION AND OPERATION


#### POWER STEERING SYSTEM

The power steering pump (Fig. 1) is a constant flow rate and displacement vane type pump. The pump reservoir is attached to the pump body. The pump is connected to the steering by the pressure and return hoses.

The steering gear (Fig. 1) used is a recirculating ball type gear. The rack piston balls act as a rolling thread between the worm shaft and rack piston. The worm shaft is supported by a thrust bearing at the lower end and a bearing assembly at the upper end. When the worm shaft is turned the rack piston moves. The rack piston teeth mesh with the pitman shaft. Turning the worm shaft turns the pitman shaft, which moves the steering linkage.

The power steering system consists of:

- Hydraulic pump
- Recirculating ball steering gear
- Steering column
- Steering linkage
- Cooler (optional)



80a1c394

**Fig. 1 Typical - Power Steering Gear & Pump**

## DIAGNOSIS AND TESTING

## POWER STEERING SYSTEM DIAGNOSIS CHARTS

*STEERING NOISE*

There is some noise in all power steering systems. One of the most common is a hissing sound evident at a standstill parking. Or when the steering wheel is at the end of it's travel. Hiss is a high frequency noise similar to that of a water tap being closed slowly. The noise is present in all valves that have a high velocity fluid passing through an orifice. There is no relationship between this noise and steering performance.

CONDITION	POSSIBLE CAUSES	CORRECTION
OBJECTIONAL HISS OR WHISTLE	<ol style="list-style-type: none"> <li>1. Steering intermediate shaft to dash panel seal.</li> <li>2. Noisy valve in power steering gear.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check and repair seal at dash panel.</li> <li>2. Replace steering gear.</li> </ol>
RATTLE OR CLUNK	<ol style="list-style-type: none"> <li>1. Gear mounting bolts loose.</li> <li>2. Loose or damaged suspension components/track bar.</li> <li>3. Loose or damaged steering linkage.</li> <li>4. Internal gear noise.</li> <li>5. Pressure hose in contact with other components.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten bolts to specification.</li> <li>2. Inspect and repair suspension.</li> <li>3. Inspect and repair steering linkage.</li> <li>4. Replace gear.</li> <li>5. Reposition hose.</li> </ol>
CHIRP OR SQUEAL	<ol style="list-style-type: none"> <li>1. Loose belt.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust or replace.</li> </ol>
WHINE OR GROWL	<ol style="list-style-type: none"> <li>1. Low fluid level.</li> <li>2. Pressure hose in contact with other components.</li> <li>3. Internal pump noise.</li> <li>4. Air in the system.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill to proper level.</li> <li>2. Reposition hose.</li> <li>3. Replace pump.</li> <li>4. Perform pump initial operation.</li> </ol>
SUCKING AIR SOUND	<ol style="list-style-type: none"> <li>1. Loose return line clamp.</li> <li>2. O-ring missing or damaged on hose fitting.</li> <li>3. Low fluid level.</li> <li>4. Air leak between pump and reservoir.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace clamp.</li> <li>2. Replace o-ring.</li> <li>3. Fill to proper level.</li> <li>4. Repair as necessary.</li> </ol>
SCRUBBING OR KNOCKING	<ol style="list-style-type: none"> <li>1. Wrong tire size.</li> <li>2. Wrong gear.</li> </ol>	<ol style="list-style-type: none"> <li>1. Verify tire size.</li> <li>2. Verify gear.</li> </ol>

DIAGNOSIS AND TESTING (Continued)

*BINDING AND STICKING*

CONDITION	POSSIBLE CAUSE	CORRECTION
DIFFICULT TO TURN WHEEL STICKS OR BINDS	<ol style="list-style-type: none"> <li>1. Low fluid level.</li> <li>2. Tire pressure.</li> <li>3. Steering component.</li> <li>4. Loose belt.</li> <li>5. Low pump pressure.</li> <li>6. Column shaft coupler binding.</li> <li>7. Steering gear worn or out of adjustment.</li> <li>8. Ball joints binding.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill to proper level.</li> <li>2. Adjust tire pressure.</li> <li>3. Inspect and lube.</li> <li>4. Adjust or replace.</li> <li>5. Pressure test and replace if necessary.</li> <li>6. Replace coupler.</li> <li>7. Repair or replace gear.</li> <li>8. Inspect and repair as necessary.</li> </ol>

*INSUFFICIENT ASST. OR POOR RETURN TO CENTER*

CONDITION	POSSIBLE CAUSE	CORRECTION
HARD TURNING OR MOMENTARY INCREASE IN TURNING EFFORT	<ol style="list-style-type: none"> <li>1. Tire pressure.</li> <li>2. Low fluid level.</li> <li>3. Loose belt.</li> <li>4. Lack of lubrication.</li> <li>5. Low pump pressure.</li> <li>6. Internal gear leak.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust tire pressure.</li> <li>2. Fill to proper level.</li> <li>3. Adjust or replace.</li> <li>4. Inspect and lubricate steering and suspension compnents.</li> <li>5. Pressure test and repair as necessary.</li> <li>6. Pressure and flow test, and repair as necessary.</li> </ol>
STEERING WHEEL DOES NOT WANT TO RETURN TO CENTER POSITION	<ol style="list-style-type: none"> <li>1. Tire pressure.</li> <li>2. Wheel alignment.</li> <li>3. Lack of lubrication.</li> <li>4. High friction in steering gear.</li> <li>5. Ball joints binding.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust tire pressure.</li> <li>2. Align front end.</li> <li>3. Inspect and lubricate steering and suspension compnents.</li> <li>4. Test and adjust as necessary.</li> <li>5. Inspect and repair as necessary.</li> </ol>


## DIAGNOSIS AND TESTING (Continued)

## LOOSE STEERING AND VEHICLE LEAD

CONDITION	POSSIBLE CAUSE	CORRECTION
EXCESSIVE PLAY IN STEERING WHEEL	<ol style="list-style-type: none"> <li>1. Worn or loose suspension or steering components.</li> <li>2. Worn or loose wheel bearings.</li> <li>3. Steering gear mounting.</li> <li>4. Gear out of adjustment.</li> <li>5. Worn or loose steering coupler.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair as necessary.</li> <li>2. Repair as necessary.</li> <li>3. Tighten gear mounting bolts to specification.</li> <li>4. Adjust gear to specification.</li> <li>5. Repair as necessary.</li> </ol>
VEHICLE PULLS OR LEADS TO ONE SIDE	<ol style="list-style-type: none"> <li>1. Tire Pressure.</li> <li>2. Radial tire lead.</li> <li>3. Brakes dragging.</li> <li>4. Wheel alignment.</li> <li>5. Weak or broken spring.</li> <li>6. Loose or worn steering or suspension components.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust tire pressure.</li> <li>2. Cross front tires.</li> <li>3. Repair as necessary.</li> <li>4. Align vehicle.</li> <li>5. Replace spring.</li> <li>6. Repair as necessary.</li> </ol>

## STEERING FLOW AND PRESSURE

The following procedure is used to test the operation of the power steering system on the vehicle. This test will provide the gallons per minute (GPM) or flow rate of the power steering pump along with the maximum relief pressure. Perform test any time a power steering system problem is present. This test will determine if the power steering pump or power steering gear is not functioning properly. The following pressure and flow test is performed using Power Steering Analyzer Tool kit 6815 (Fig. 2) and Adapter Kit 6893.



80ae82e2

Fig. 2 Power Steering Analyzer

## FLOW AND PRESSURE TEST

(1) Check the power steering belt to ensure it is in good condition and adjusted properly.

(2) Connect pressure gauge hose from the Power Steering Analyzer to Tube 6865.

(3) Connect Adapter 6826 to Power Steering Analyzer test valve end.

(4) Disconnect the high pressure hose from the power steering pump.

(5) Connect Tube 6865 to the pump hose fitting.

(6) Connect the power steering hose from the steering gear to Adapter 6826.

(7) Open the test valve completely.

(8) Start engine and let idle long enough to circulate power steering fluid through flow/pressure test gauge.

(9) Shut off the engine and check the fluid level, add fluid as necessary. Start engine again and let idle.

(10) The initial pressure reading should be 345-552 kPa (50-80 psi). If pressure is higher inspect the hoses for restrictions and repair as necessary.

(11) Increase the engine speed to 1500 RPM and read the flow meter. The reading should be 2.4 - 2.8 GPM, if the reading is below this specification the pump should be replaced.

**CAUTION:** This next step involves testing maximum pump pressure output and flow control valve operation. Do not leave valve closed for more than three seconds as the pump could be damaged.

(12) Close valve fully three times for three seconds and record highest pressure indicated each time. **All three readings must be at pump relief pressure**

DIAGNOSIS AND TESTING (Continued)

**specifications and within 345 kPa (50 psi) of each other.**

- Pressures above specifications but not within 345 kPa (50 psi) of each other, replace pump.
- Pressures within 345 kPa (50 psi) of each other but below specifications, replace pump.

(13) Open the test valve and turn the steering wheel to the extreme left and right positions against the stops. Record the highest pressure reading at each position. Compare readings to the pump specifications chart. If pressures readings are not within 50 psi. of each other, the gear is leaking internally and must be repaired.

**CAUTION: Do not force the pump to operate against the stops for more than 2 to 4 seconds at a time because, pump damage will result.**

*PUMP SPECIFICATIONS*

ENGINE	RELIEF PRESSURE ± 50	FLOW RATE (GPM)
4.0L	9653 kPa (1400 psi)	1500 RPM
4.7L	9653 kPa (1400 psi)	2.4 - 2.8 GPM

# POWER STEERING PUMP

## INDEX

	page		page
<b>DESCRIPTION AND OPERATION</b>		POWER STEERING PUMP - 4.7L .....	8
POWER STEERING PRESSURE LINE .....	6	<b>DISASSEMBLY AND ASSEMBLY</b>	
POWER STEERING PUMP .....	6	PUMP PULLEY .....	8
POWER STEERING RETURN LINE .....	6	PUMP RESERVOIR .....	8
<b>DIAGNOSIS AND TESTING</b>		<b>SPECIFICATIONS</b>	
PUMP LEAKAGE DIAGNOSIS .....	7	TORQUE CHART .....	9
<b>SERVICE PROCEDURES</b>		<b>SPECIAL TOOLS</b>	
POWER STEERING PUMP – INITIAL OPERATION .....	7	POWER STEERING PUMP .....	9
<b>REMOVAL AND INSTALLATION</b>			
POWER STEERING PUMP - 4.0L .....	7		

## DESCRIPTION AND OPERATION


### POWER STEERING PUMP

Hydraulic pressure for the power steering system is provided by a belt driven power steering pump (Fig. 1). The pump shaft has a pressed-on drive pulley that is belt driven by the crankshaft pulley. The power steering pump is a constant flow rate and displacement, vane-type pump. The pump internal parts operate submerged in fluid. The flow control orifice is part of the high pressure line fitting. The pressure relief valve inside the flow control valve limits the pump pressure. The reservoir is attached to the pump body with spring clips. The power steering pump is connected to the steering gear by the pressure and return hoses.

**NOTE:** Power steering pumps have different pressure rates and are not interchangeable with other pumps.

### POWER STEERING PRESSURE LINE

Power steering pressure line, is used to transfer high pressure power steering fluid, from the power steering pump to the power steering gear. The hose consists of two metal ends and rubber center section that contains a tuning cable.




*Fig. 1 Pump With Integral Reservoir*

### POWER STEERING RETURN LINE

Power steering return line, is used to transfer low pressure power steering fluid, from the power steering gear to the power steering pump. The hose is clamped at the pump and the gear.

## DIAGNOSIS AND TESTING

### PUMP LEAKAGE DIAGNOSIS



1. BUSHING (BEARING) WORN, SEAL WORN. REPLACE PUMP.
2. REPLACE RESERVOIR O-RING SEAL.
3. TORQUE HOSE FITTING NUT TO SPECIFICATIONS. IF LEAKAGE PERSISTS, REPLACE O-RING SEAL.
4. TORQUE FITTING TO SPECIFICATIONS. IF LEAKAGE PERSISTS, REPLACE O-RING SEAL.
5. REPLACE PUMP.
6. CHECK OIL LEVEL: IF LEAKAGE PERSISTS WITH THE LEVEL CORRECT AND CAP TIGHT, REPLACE THE CAP.

80a1c3c3

## SERVICE PROCEDURES

### POWER STEERING PUMP – INITIAL OPERATION

**WARNING: THE FLUID LEVEL SHOULD BE CHECKED WITH ENGINE OFF TO PREVENT INJURY FROM MOVING COMPONENTS.**

**CAUTION: Use MOPAR Power Steering Fluid or equivalent. Do not use automatic transmission fluid and do not overfill.**

Wipe filler cap clean, then check the fluid level. The dipstick should indicate **COLD** when the fluid is at normal ambient temperature.

(1) Fill the pump fluid reservoir to the proper level and let the fluid settle for at least two minutes.

(2) Start the engine and let run for a few seconds then turn engine off.

(3) Add fluid if necessary. Repeat the above procedure until the fluid level remains constant after running the engine.

(4) Raise the front wheels off the ground.

(5) Slowly turn the steering wheel right and left, lightly contacting the wheel stops at least 20 times.

(6) Check the fluid level add if necessary.

(7) Lower the vehicle, start the engine and turn the steering wheel slowly from lock to lock.

(8) Stop the engine and check the fluid level and refill as required.

(9) If the fluid is extremely foamy or milky looking, allow the vehicle to stand a few minutes and repeat the procedure.

**CAUTION: Do not run a vehicle with foamy fluid for an extended period. This may cause pump damage.**

## REMOVAL AND INSTALLATION

### POWER STEERING PUMP - 4.0L

#### REMOVAL

(1) Remove serpentine drive belt, refer to Group 7 Cooling.

(2) Remove pressure and return hoses from pump and drain pump.

(3) Remove 3 pump mounting bolts through pulley access holes.

(4) Tilt pump downward and remove from engine.

(5) Remove pulley from pump.

#### INSTALLATION

(1) Install pulley on pump.

(2) Install pump on engine.

(3) Install 3 pump mounting bolts and tighten to 28 N·m (21 ft. lbs.).

(4) Install the pressure and return hoses to pump.

(5) Install drive belt, refer to Group 7 Cooling.

(6) Add power steering fluid. Refer to Power Steering Pump Initial Operation.

## REMOVAL AND INSTALLATION (Continued)

## POWER STEERING PUMP - 4.7L

## REMOVAL

- (1) Remove the serpentine drive belt. Refer to Group 7 Cooling.
- (2) Remove the pressure and return hoses from pump and drain pump.
- (3) Remove 3 pump mounting bolts through pulley access holes (Fig. 2).
- (4) Remove the pump from the vehicle.




Fig. 2 Pump Mounting

## INSTALLATION

- (1) Position the pump on the left cylinder head and install bolts through pulley access holes. Tighten bolts to 40 N·m (30 ft. lbs.).
- (2) Install the pressure and return hoses to pump.
- (3) Install serpentine drive belt, refer to Group 7 Cooling.
- (4) Add power steering fluid. Refer to Power Steering Pump Initial Operation in this section.

## DISASSEMBLY AND ASSEMBLY

## PUMP PULLEY

## DISASSEMBLY

- (1) Remove pump assembly.
- (2) Remove pulley from pump with Puller C-4333 (Fig. 3).

## ASSEMBLY

- (1) Replace pulley if bent, cracked, or loose.




Fig. 3 Pulley Removal

- (2) Install pulley on pump with Installer C-4063-B (Fig. 4) flush with the end of the shaft. Ensure the tool and pulley remain aligned with the pump shaft.




Fig. 4 Pulley Installation

- (3) Install pump assembly.
- (4) With Serpentine Belt, run engine until warm (5 min.) and note any belt chirp. If chirp exists, move pulley outward approximately 0.5 mm (0.020 in.). If noise increases, press on 1.0 mm (0.040 in.). **Be careful that pulley does not contact mounting bolts.**

## PUMP RESERVOIR


## DISASSEMBLY

- (1) Remove power steering pump.
- (2) Clean exterior of pump.
- (3) Clamp the pump body in a soft jaw vice.
- (4) Pry up tab and slide the retaining clips off (Fig. 5).

**NOTE:** Use new retaining clips for installation.



DISASSEMBLY AND ASSEMBLY (Continued)



**Fig. 5 Pump Reservoir Clips**

(5) Remove fluid reservoir from pump body. Remove and discard O-ring seal.

**ASSEMBLY**


- (1) Lubricate new O-ring Seal with Mopar Power Steering Fluid or equivalent.
- (2) Install O-ring seal in housing.
- (3) Install reservoir onto housing.
- (4) Slide and tap in **new** reservoir retainer clips until tab locks to housing.
- (5) Install power steering pump.
- (6) Add power steering fluid, refer to Pump Initial Operation.

**SPECIFICATIONS**


**TORQUE CHART**

<b>DESCRIPTION</b>	<b>TORQUE</b>
<b>Power Steering Pump</b>	
Bracket Bolt-4.0L . . . . .	57 N·m (42 ft. lbs.)
Pump Bolts-4.0L . . . . .	28 N·m (21 ft. lbs.)
Pump Bolts-4.7L . . . . .	40 N·m (30 ft. lbs.)
Flow Control Valve . . . . .	75 N·m (55 ft. lbs.)
Pressure Line . . . . .	20-38 N·m (14-28 ft. lbs.)
Return Line . . . . .	20-38 N·m (14-28 ft. lbs.)


**SPECIAL TOOLS**  
**POWER STEERING PUMP**




**Analyzer Set, Power Steering Flow/Pressure 6815**



**Adapters, Power Steering Flow/Pressure Tester 6893**



**Puller C-4333**



**Installer, Power Steering Pulley C-4063-B**

# POWER STEERING GEAR

## INDEX

	page		page
<b>DESCRIPTION AND OPERATION</b>		RACK PISTON/VALVE ASSEMBLY .....	14
POWER STEERING GEAR .....	10	STUB SHAFT HOUSING .....	12
<b>DIAGNOSIS AND TESTING</b>		<b>ADJUSTMENTS</b>	
POWER STEERING GEAR LEAKAGE		STEERING GEAR .....	17
DIAGNOSIS .....	11	<b>SPECIFICATIONS</b>	
<b>REMOVAL AND INSTALLATION</b>		POWER STEERING GEAR .....	18
STEERING GEAR .....	11	TORQUE CHART .....	18
<b>DISASSEMBLY AND ASSEMBLY</b>		<b>SPECIAL TOOLS</b>	
PITMAN SHAFT/SEALS/BEARINGS .....	12	POWER STEERING GEAR .....	18

## DESCRIPTION AND OPERATION


### POWER STEERING GEAR

The power steering gear is a recirculating ball type gear (Fig. 1). The gear acts as a rolling thread between the worm shaft and rack piston. The worm shaft is supported by a thrust bearing at the lower end and a bearing assembly at the upper end. When the worm shaft is turned the rack piston moves. The rack piston teeth mesh with the pitman shaft. Turning the worm shaft turns the pitman shaft, which turns the steering linkage.

The following gear components can be serviced:

- Pitman Shaft and Cover
- Pitman Shaft Bearings
- Pitman Shaft Oil Seal/Dust Seal
- Stud Shaft Housing with Seal
- O-Rings and Teflon Rings


**NOTE:** If rack piston assembly is damaged the gear must be replaced.



80b5cb09


Fig. 1 Recirculating Ball Type Gear

**DIAGNOSIS AND TESTING**  
**POWER STEERING GEAR LEAKAGE DIAGNOSIS**



- |  |  |
|--|--|
| <p>1. SIDE COVER LEAK - TORQUE SIDE COVER BOLTS TO SPECIFICATION. REPLACE THE SIDE COVER SEAL IF THE LEAKAGE PERSISTS.</p> <p>2. ADJUSTER PLUG SEAL - REPLACE THE ADJUSTER PLUG SEALS.</p> | <p>3. PRESSURE LINE FITTING - TORQUE THE HOSE FITTING NUT TO SPECIFICATIONS. IF LEAKAGE PERSISTS, REPLACE THE SEAL.</p> <p>4. PITMAN SHAFT SEALS - REPLACE THE SEALS.</p> <p>5. TOP COVER SEAL - REPLACE THE SEAL.</p> |
|--|--|

80a1c3c2



80b5cc7a

**Fig. 2 Pressure And Return Lines**


**REMOVAL AND INSTALLATION**  
**STEERING GEAR**

**REMOVAL**

- (1) Place the front wheels in the straight ahead position with the steering wheel centered.
- (2) Remove the air cleaner housing, refer to Group 14 Fuel System.
- (3) Remove and cap the pressure and return lines (Fig. 2) from the steering gear.
- (4) Remove the column coupler shaft bolt (Fig. 2) and remove the shaft from the gear.
- (5) Remove left front wheel and tire assembly.
- (6) Remove pitman arm from gear with Puller C-4150A.
- (7) Remove windshield washer reservoir refer to Group 8 Electrical.
- (8) Remove the steering gear mounting bolts. Remove the steering gear out of the engine compartment (Fig. 3).

**INSTALLATION**

- (1) Position the steering gear on the frame rail and install the bolts. Tighten the bolts to 108 N·m (80 ft. lbs.) torque.



80b6f085

**Fig. 3 Steering Gear Mounting**

- (2) Install the pitman arm and tighten nut to 251 N·m (185 ft. lbs.).
- (3) Install windshield washer reservoir refer to Group 8 Electrical.
- (4) Install the wheel and tire assembly.
- (5) Install the pressure and return hoses to the steering gear and tighten to 20-38 N·m (14-28 ft. lbs.).
- (6) Install the column coupler shaft.
- (7) Install the air cleaner housing refer to Group 14 Fuel System.
- (8) Fill the power steering pump.


## DISASSEMBLY AND ASSEMBLY

## STUB SHAFT HOUSING

**NOTE:** If stub shaft housing, seal or bearing is damaged the housing must be replaced.


## DISASSEMBLY

- (1) Remove stub shaft housing bolts (Fig. 4).
- (2) Remove housing from the steering gear (Fig. 5).
- (3) Remove stub shaft housing o-rings (Fig. 6).



80b5cc7e

Fig. 4 Stub Shaft Housing




80b4b857

Fig. 5 Housing Removal

## ASSEMBLY

- (1) Grease stub shaft seal with **special grease** supplied with new stub shaft housing.
- (2) Install new stub shaft housing o-rings.
- (3) Install housing on the steering gear.
- (4) Install the housing bolts and tighten to 62 N·m (46 ft. lbs.).



80b4b858


Fig. 6 O-Rings

## PITMAN SHAFT/SEALS/BEARINGS

## DISASSEMBLY

- (1) Clean exposed end of pitman shaft and housing with a wire brush.
- (2) Rotate the stub shaft with a wrench (Fig. 7) from stop to stop and count the number of turns.
- (3) Center the stub shaft by rotating it from the stop 1/2 of the total amount of turns.

**NOTE:** The pitman shaft will not clear the housing if it is not centered.




80b4f9d0


Fig. 7 Center Stub Shaft

- (4) Remove pitman shaft cover bolts and remove the shaft assembly (Fig. 8).
- (5) Remove pitman shaft cover o-ring.
- (6) Remove pitman shaft dust seal from the housing with a Puller 7794-A and Slide Hammer C-637 (Fig. 9).
- (7) Remove the pitman shaft oil seal retaining ring with snap ring pliers (Fig. 10).

DISASSEMBLY AND ASSEMBLY (Continued)



**Fig. 8 Cover and Pitman Shaft**



**Fig. 9 Dust Seal Removal**

(8) Remove oil seal metal backup washer then plastic backup washer from the housing (Fig. 11).


(9) Remove pitman shaft oil seal from the housing with a Puller 7794-A and Slide Hammer C-637 (Fig. 12).

(10) Drop Driver 8277 through the top bearing and align the driver up with the lower bearing. (Fig. 13). Install Handle C-4171 into the driver and remove the lower bearing.


(11) Turn the gear over and remove the upper bearing with Driver 8277 and Handle C-4171.

**ASSEMBLY**


(1) Install upper pitman shaft bearing, with Driver 8294 and Handle C-4171 (Fig. 14). Drive bearing into housing until the driver bottoms out.



**Fig. 10 Oil Seal Retaining Ring**




**Fig. 11 Backup Washers**



**Fig. 12 Oil Seal Removal**


**NOTE:** Install upper pitman shaft bearing with the part number/letters facing the driver.

## DISASSEMBLY AND ASSEMBLY (Continued)



80b5cb4f


Fig. 13 Bearing Driver



80b6b1a5

Fig. 14 Upper Pitman Shaft Bearing

(2) Install lower pitman shaft bearing with the other side Driver 8294 and Handle C-4171 (Fig. 15). Drive bearing into housing until the bearing shoulder is seated against the housing.



80b6b1a6

Fig. 15 Lower Pitman Shaft Bearing

(3) Coat the oil seal and backup washers with **special grease** supplied with the new seal.

(4) Install the oil seal with Driver 8294 and Handle C-4171.

(5) Install plastic backup washer.

**NOTE:** The plastic backup washer has a lip on the inside diameter that faces down towards the oil seal.

(6) Install metal backup washer.

(7) Install the retainer ring with snap ring pliers.

(8) Coat the dust seal with **special grease** supplied with the new seal.

(9) Install dust seal with Driver 8294 and Handle C-4171.

(10) Install new pitman shaft cover o-ring.

(11) Install pitman shaft assembly into the housing.

(12) Install cover bolts and tighten to 62 N-m (46 ft. lbs.).

(13) Perform over-center rotation torque adjustment.

## RACK PISTON/VALVE ASSEMBLY


## DISASSEMBLY

(1) Clean exposed end of pitman shaft and housing with a wire brush.

(2) Rotate the stub shaft with a wrench (Fig. 16) from stop to stop and count the number of turns.

(3) Center the stub shaft by rotating it from the stop 1/2 of the total amount of turns.

**NOTE:** The pitman shaft will not clear the housing if it is not centered.




80b4f9d0

Fig. 16 Center Stub Shaft

(4) Remove pitman shaft cover bolts and remove the shaft assembly (Fig. 17).

(5) Remove the pitman shaft cover o-ring.


DISASSEMBLY AND ASSEMBLY (Continued)



**Fig. 17 Cover and Pitman Shaft**

80b4f9d1

(6) Remove stub shaft housing bolts (Fig. 18).



**Fig. 18 Stub Shaft Housing**

80b5cb06

(7) Remove the housing from the stub shaft (Fig. 19).


(8) Remove stub shaft housing o-rings (Fig. 20).

(9) Remove the rack piston/valve assembly retaining ring with snap ring pliers (Fig. 21).

(10) Pull the rack piston/valve assembly out of the gear housing (Fig. 22).


**NOTE:** If the rack piston is damage the gear assembly must be replaced.

(11) Remove teflon rings and o-ring (Fig. 23) from the rack piston/valve assembly.




80b5cb07

**Fig. 19 Housing Removal**



80b4b858


**Fig. 20 O-Rings**



80b4f9d5

**Fig. 21 Retaining Ring**


## DISASSEMBLY AND ASSEMBLY (Continued)



80b4f9d7

Fig. 22 Rack Piston/Valve Assembly

**CAUTION:** The rack piston teflon ring and o-ring must be replaced whenever the assembly is removed from the housing.



80b6b1a3

Fig. 23 Teflon Rings And O-Ring

(12) Remove pitman shaft dust seal from the housing with Puller 7794-A and Slide Hammer C-637 (Fig. 24).

(13) Remove pitman shaft oil seal retaining ring from the housing with snap ring pliers (Fig. 25).

(14) Remove metal backup washer then plastic backup washer from the housing (Fig. 26).


(15) Remove oil seal from the housing with a Puller 7794-A and Slide Hammer C-637 (Fig. 27).

**ASSEMBLY**

(1) Coat the oil seal and backup washers with **special grease** supplied with the new seal.


(2) Install the oil seal with Driver 8294 and Handle C-4171.

(3) Install plastic backup washer.




80b4f9d6

Fig. 24 Dust Seal



80b4f9d3

Fig. 25 Oil Seal Retaining Ring




80b4f9d4

Fig. 26 Oil Seal Backup Washers

**NOTE:** The plastic backup washer has a lip on the inside diameter that faces down towards the oil seal.



DISASSEMBLY AND ASSEMBLY (Continued)



**Fig. 27 Oil Seal Removal**

- (4) Install metal backup washer.
- (5) Install the retainer ring with snap ring pliers.
- (6) Coat the dust seal with **special grease** supplied with the new seal.
- (7) Install dust seal with Driver 8294 and Handle C-4171.
- (8) Lubricate new o-ring and teflon rings with power steering fluid and install on the rack piston/valve assembly.
- (9) Lubricate the rack piston/valve assembly with power steering fluid.
- (10) Slide the assembly into the gear housing.
- (11) Install new stub shaft housing o-rings and install the housing. Tighten the housing bolts to 62 N·m (46 ft. lbs.).
- (12) Install new o-ring on the pitman shaft cover.
- (13) Install the pitman shaft into the gear housing.
- (14) Install the pitman shaft cover bolts and tighten to 62 N·m (46 ft. lbs.).
- (15) Perform over-center rotation torque adjustment.

ADJUSTMENTS

STEERING GEAR

**NOTE:** Adjusting the steering gear in the vehicle is not recommended. Remove gear from the vehicle and drain the fluid. Then mount gear in a vise to perform adjustments.

OVER-CENTER

- (1) Rotate the stub shaft with Socket 8343 from stop to stop and count the number of turns.
- (2) Center the stub shaft by rotating it from the stop 1/2 of the total amount of turns.


(3) Place torque wrench and Socket 8343 in a vertical position on the stub shaft. Rotate the wrench 45 degrees each side of the center and record the highest rotational torque in this range (Fig. 28). This is the Over-Center Rotating Torque.

**NOTE:** The stub shaft must rotate smoothly without sticking or binding.

(4) Rotate the stub shaft between 90° and 180° to the left of center and record the left off-center preload. Repeat this to the right of center and record the right off-center preload. The average of these two recorded readings is the Preload Rotating Torque.

(5) The Over-Center Rotating Torque should be 0.45-0.80 N·m (4-7 in. lbs.) **higher** than the Preload Rotating Torque.

(6) If an adjustment to the Over-Center Rotating Torque is necessary, first loosen the adjuster lock nut. Then turn the pitman shaft adjuster screw back (COUNTERCLOCKWISE) until fully extended, then turn back in (CLOCKWISE) one full turn.



**Fig. 28 Checking Over-center Rotation Torque**

(7) Remeasure Over-Center Rotating Torque. If necessary turn the adjuster screw and repeat measurement until correct Over-Center Rotating Torque is reached.

**NOTE:** To increase the Over-Center Rotating Torque turn the screw **CLOCKWISE**.

(8) Prevent the adjuster screw from turning while tightening adjuster lock nut. Tighten the adjuster lock nut to 37-52 N·m (27-38 ft. lbs.).

SPECIFICATIONS

POWER STEERING GEAR

**Steering Gear**

Type . . . . . Recirculating Ball

Overall Ratio . . . . . 12.7:1

**Pitman Shaft Overcenter Drag**

New Gear (under 400 miles) . . . . . 0.45-0.80 N·m  
(4-7 in. lbs.)

+ Worm Shaft Preload

Used Gear (over 400 miles) . . . . . 0.5-0.6 N·m  
(4-5 in. lbs.)

+ Worm Shaft Preload

TORQUE CHART

**DESCRIPTION**

**TORQUE**

**Power Steering Gear**

Adjustment Screw Locknut . . 37-52 N·m (27-38 ft.  
lbs.)

Gear to Frame Bolts . . . . . 108 N·m (80 ft. lbs.)


Pitman Shaft Nut . . . . . 251 N·m (185 ft. lbs.)

Pitman Shaft Cover Bolts . . . . 62 N·m (46 ft. lbs.)


Stub Shaft Housing Bolts . . . . 62 N·m (46 ft. lbs.)

Pressure Line . . . . . 20-38 N·m (14-28 ft. lbs.)

Return Line . . . . . 20-38 N·m (14-28 ft. lbs.)




**Remover, Pitman Arm C-4150A**




**Handle C-4171**

SPECIAL TOOLS


POWER STEERING GEAR



**Puller Seal 7794-A**




**Driver 8277**




**Slide Hammer C-637**

SPECIAL TOOLS (Continued)



***Driver 8294***



***Socket 8343***

# STEERING LINKAGE


## INDEX

	page		page
<b>DESCRIPTION AND OPERATION</b>		PITMAN ARM . . . . .	21
DRAG LINK AND ENDS . . . . .	20	STEERING DAMPER . . . . .	22
PITMAN ARM . . . . .	20	TIE ROD . . . . .	20
STEERING DAMPER . . . . .	20	<b>SPECIFICATIONS</b>	
STEERING LINKAGE . . . . .	20	TORQUE CHART . . . . .	22
TIE ROD ENDS . . . . .	20	<b>SPECIAL TOOLS</b>	
<b>REMOVAL AND INSTALLATION</b>		STEERING LINKAGE . . . . .	23
DRAG LINK . . . . .	21		

## DESCRIPTION AND OPERATION

### STEERING LINKAGE

The steering linkage consists of a pitman arm, drag link, tie rod, and steering dampener (Fig. 1). An adjustment sleeve on the tie rod is used to set wheel toe position. The sleeve on the drag link is used for steering wheel centering.



*Fig. 1 Steering Linkage*

**CAUTION:** If any steering components are replaced or serviced an alignment must be performed, to ensure the vehicle meets all alignment specifications.

**CAUTION:** Components attached with a nut and cotter pin must be torqued to specification. Then if the slot in the nut does not line up with the cotter pin hole, tighten nut until it is aligned. Never loosen the nut to align the cotter pin hole.

### TIE ROD ENDS

The tie rod ends connect the drag link to the wheel assembly. The ends are forged, with a lubed for life ball socket. The tie rod provides toe alignment and transfers steering input from the drag link to the wheels.

### PITMAN ARM

The pitman arm is attached at one end of the steering gear's sector shaft. The other end is connected to the drag link. The pitman arm transfers rotary motion into side to side motion. The arm is splined to the steering gear shaft.

### DRAG LINK AND ENDS

The drag link and ends are comprised of two forged ends connected by a steel adjusting tube. The drag link connects the steering gear pitman arm to the steering knuckle. The larger offset end is attached to the pitman arm. The sleeve is used for steering wheel centering.

### STEERING DAMPER

The steering damper provides steering system dampening. The damper is mounted to the axle housing and the tie rod end. The damper consists of steel tube shock absorber with a permanent bushed end.

## REMOVAL AND INSTALLATION

### TIE ROD

#### REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove wheel and tire assemblies.
- (3) Remove the damper cotter pin and nut from the tie rod (Fig. 2).

REMOVAL AND INSTALLATION (Continued)

- (4) Remove the damper from the tie rod with Puller C-3894-A.
- (5) Remove the cotter pins and nuts from the tie rod ends at the steering knuckles (Fig. 2).
- (6) Remove the tie rod ends from the steering knuckles with Puller C-3894-A.
- (7) Loosen the adjustment sleeve clamp bolts and unscrew the tie rod ends from the sleeve.




Fig. 2 Tie Rod Assembly

INSTALLATION

- (1) Screw the tie rod ends into the adjustment sleeve.
- (2) Install the tie rod on the steering knuckles and install the nuts.
- (3) Tighten the nuts to 47 N·m (35 ft. lbs.). Install new cotter pins and bend end 60°.
- (4) Position the adjustment sleeve clamp bolts to their original location and tighten to 68 N·m (50 ft. lbs.).
- (5) Install the damper on the tie rod and install the nut.
- (6) Tighten the nut to 68 N·m (50 ft. lbs.). Install new cotter pins and bend end 60°.
- (7) Install wheel and tire assemblies.
- (8) Remove support and lower the vehicle.
- (9) Perform toe position adjustment.

PITMAN ARM

REMOVAL

- (1) Remove the cotter pin and nut from the drag link at the pitman arm (Fig. 3).
- (2) Remove the drag link ball stud from the pitman arm with a puller.
- (3) Remove the nut and washer from the steering gear shaft. Mark the pitman shaft and pitman arm for installation reference. Remove the pitman arm from steering gear with Puller C-4150A (Fig. 4).




Fig. 3 Pitman Arm




Fig. 4 Pitman Arm Removal

INSTALLATION

- (1) Align and install the pitman arm on steering gear shaft.
- (2) Install the washer and nut on the shaft and tighten the nut to 251 N·m (185 ft. lbs.).
- (3) Install drag link ball stud to pitman arm. Install nut and tighten to 88 N·m (65 ft. lbs.). Install a new cotter pin.

DRAG LINK

REMOVAL

- (1) Raise and support the vehicle.
- (2) Remove right wheel and tire assembly.
- (3) Remove the cotter pins and nuts at the right steering knuckle and pitman arm (Fig. 5).

REMOVAL AND INSTALLATION (Continued)

- (4) Remove the drag link from the steering knuckle and pitman arm Puller C-3894-A.
- (5) Loosen adjustment sleeve clamp bolts and unscrew the tie rod ends from the adjustment sleeve.




Fig. 5 Drag Link Assembly




Fig. 6 Steering Damper Puller

INSTALLATION

- (1) Screw the tie rod ends into the adjustment sleeve.
- (2) Install the drag link onto the right steering knuckle and pitman arm.
- (3) Tighten the nut at the steering knuckle to 47 N·m (35 ft. lbs.). Tighten the pitman nut to 88 N·m (65 ft. lbs.). Install new cotter pins.
- (4) Position clamp bolts to their original position and tighten to 68 N·m (50 ft. lbs.).
- (5) Install right wheel and tire assembly.
- (6) Remove support and lower the vehicle.
- (7) Center the steering wheel.




Fig. 7 Steering Damper

STEERING DAMPER

REMOVAL

- (1) Remove the cotter pin and nut from the ball stud at the tie rod.
- (2) Remove the steering damper from the tie rod with Puller C-3894-A (Fig. 6).
- (3) Remove the steering damper nut and bolt from the axle bracket (Fig. 7).

INSTALLATION


- (1) Install the steering damper to the axle bracket and tie rod.
- (2) Install the steering damper bolt in the axle bracket and tighten bolt to 88 N·m (65 ft. lbs.).
- (3) Install the nut at the tie rod and tighten to 68 N·m (50 ft. lbs.). Install a new cotter pin.

SPECIFICATIONS


TORQUE CHART

DESCRIPTION	TORQUE
<b>Pitman Arm</b>	
Shaft Nut . . . . .	251 N·m (185 ft. lbs.)
<b>Drag Link</b>	
Pitman Arm Nut . . . . .	88 N·m (65 ft. lbs.)
Knuckle Nut . . . . .	47 N·m (35 ft. lbs.)
Clamp Nuts . . . . .	68 N·m (50 ft. lbs.)
<b>Tie Rod</b>	
Knuckle Nut . . . . .	47 N·m (35 ft. lbs.)
Clamp Nuts . . . . .	68 N·m (50 ft. lbs.)
<b>Steering Damper</b>	
Axle Bolt . . . . .	88 N·m (65 ft. lbs.)
Tie Rod Nut . . . . .	68 N·m (50 ft. lbs.)

SPECIAL TOOLS  
STEERING LINKAGE



***Puller C-3894-A***



***Remover Pitman C-4150A***

# STEERING COLUMN


## INDEX

	page		page
<b>DESCRIPTION AND OPERATION</b>		<b>SPECIFICATIONS</b>	
STEERING COLUMN .....	24	TORQUE CHART .....	28
<b>REMOVAL AND INSTALLATION</b>		<b>SPECIAL TOOLS</b>	
STEERING COLUMN .....	24	STEERING COLUMN .....	28

## DESCRIPTION AND OPERATION

### STEERING COLUMN

The tilt column (Fig. 1) has been designed to be serviced as an assembly, less the wiring, switches, shrouds, steering wheel, etc. Most steering column components can be serviced without removing the steering column from the vehicle.



80b6f0a2

*Fig. 1 Steering Column*

### SERVICE WARNINGS AND CAUTIONS

To service the steering wheel, switches or airbag, refer to Group 8M and follow all WARNINGS and CAUTIONS.

**WARNING: THE AIRBAG SYSTEM IS A SENSITIVE, COMPLEX ELECTRO-MECHANICAL UNIT. BEFORE ATTEMPTING TO DIAGNOSE, REMOVE OR INSTALL THE AIRBAG SYSTEM COMPONENTS YOU MUST FIRST DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE. THEN WAIT TWO MINUTES FOR THE SYSTEM CAPACITOR TO DISCHARGE. FAILURE TO DO SO COULD RESULT IN ACCIDENTAL DEPLOYMENT OF THE AIRBAG AND POSSIBLE PERSONAL INJURY. THE FASTENERS, SCREWS, AND BOLTS, ORIGINALLY USED FOR THE AIRBAG COMPONENTS, HAVE SPECIAL COAT-**

**INGS AND ARE SPECIFICALLY DESIGNED FOR THE AIRBAG SYSTEM. THEY MUST NEVER BE REPLACED WITH ANY SUBSTITUTES. ANYTIME A NEW FASTENER IS NEEDED, REPLACE WITH THE CORRECT FASTENERS PROVIDED IN THE SERVICE PACKAGE OR FASTENERS LISTED IN THE PARTS BOOKS.**

**CAUTION: Safety goggles should be worn at all times when working on steering columns.**

## REMOVAL AND INSTALLATION

### STEERING COLUMN

**WARNING: BEFORE SERVICING THE STEERING COLUMN THE AIRBAG SYSTEM MUST BE DISARMED. FAILURE TO DO SO MAY RESULT IN ACCIDENTAL DEPLOYMENT OF THE AIRBAG AND POSSIBLE PERSONAL INJURY. REFER TO GROUP 8M RESTRAINT SYSTEMS FOR SERVICE PROCEDURES.**

### REMOVAL


- (1) Position front wheels straight ahead.
- (2) Disconnect and isolate the negative (ground) cable from the battery.
- (3) Remove the airbag, refer to Group 8M Restraint Systems for service procedures.
- (4) Remove the steering wheel nut and remove wheel with Puller C-3894-A (Fig. 2).

**NOTE: Ensure the puller jaws are seated in the pockets (Fig. 3) of the steering wheel armature.**

- (5) Remove the cluster bezel by pulling it from the instrument panel (Fig. 4).
- (6) Remove the knee blocker cover (Fig. 5), refer to Group 8E Instrument Panel Systems.
- (7) Remove the lower steering column shroud mounting screw (Fig. 6).



REMOVAL AND INSTALLATION (Continued)




**Fig. 2 Steering Wheel Puller**

80b6f088




**Fig. 3 Steering Wheel Pockets**

80b6f089




**Fig. 4 Cluster Bezel**

80b6f08a



**Fig. 5 Knee Blocker Cover**

80b6f08b




**Fig. 6 Column Shroud Mounting Screw**

80b6f090


## REMOVAL AND INSTALLATION (Continued)

(8) Unsnap the two halves of the column shrouds by pressing on the sides of the upper shroud and tilting the rear of the upper shroud up. Remove the shrouds from the steering column (Fig. 7).



**Fig. 7 Column Shrouds**

(9) Remove the upper fixed shroud mounting screws and remove the shroud (Fig. 8).




**Fig. 8 Upper Fixed Shroud**


(10) Disconnect the multifunction switch (Fig. 9) and ignition switch harness.

(11) Remove the multifunction switch screw from underneath the switch (Fig. 10). Slide the multifunction switch and clock spring off the column as an assembly (Fig. 11).


(12) Turn the ignition key to the on position then release and remove the shifter interlock cable (Fig. 12) from the ignition lock cylinder housing.



**Fig. 9 Multifunction Switch Harness**




**Fig. 10 Multifunction Switch Screw**




**Fig. 11 Multifunction Switch And Clock Spring**

## REMOVAL AND INSTALLATION (Continued)



**Fig. 12 Shifter Interlock Cable**

(13) Remove the column coupler bolt (Fig. 13) and slide the coupler off the column shaft.



**Fig. 13 Column Coupler Bolt And Mounting Nuts**


(14) Remove the column mounting nuts (Fig. 13) and lower column off mounting studs. Remove the column from the vehicle.

(15) Remove the ignition switch, cylinder and SKIM (Fig. 14), refer to Group 8D Ignition System.

## INSTALLATION

(1) Install the ignition switch, cylinder and SKIM, refer to Group 8D Ignition System.

(2) Install the column into the vehicle and lift the column up onto the mounting studs. Install the mounting nuts and tighten to 12 N·m (105 in. lbs.).



**Fig. 14 Ignition Switch And SKIM**

(3) Slid the coupler onto the column shaft and install the coupler bolt. Tighten the coupler bolt to 49 N·m (36 ft. lbs.).

(4) Turn the ignition key to the on position then release and install the shifter interlock cable (Fig. 12) into ignition lock cylinder housing.

(5) Slide the multifunction switch and clock spring onto the column as an assembly (Fig. 11).

(6) Install the multifunction switch mounting screw (Fig. 10).

(7) Connect the multifunction switch (Fig. 9) and ignition switch harness.

(8) Install the upper fixed shroud and mounting screws (Fig. 8).

(9) Install the lower steering column shroud to the steering column. Install and tighten the mounting screw.

(10) Install the upper column shroud. Align the upper shroud to the lower shroud and snap the two shroud halves together.

(11) Install the knee blocker cover (Fig. 5), refer to Group 8E Instrument Panel Systems.

(12) Install the cluster bezel by pulling it from the instrument panel (Fig. 4).

(13) Align the steering wheel with the column index spline and install the wheel on the column shaft. Pull the clockspring wire harness through the steering wheel armature spokes.

(14) Install and tighten the steering wheel mounting nut to 61 N·m (45 ft. lbs.).

(15) Connect the steering wheel wire harness connector to the clock spring connector.

(16) Install the airbag, refer to Group 8M Restraint Systems for service procedures.

(17) Connect the negative (ground) cable to the battery.

## SPECIFICATIONS

## TORQUE CHART

**DESCRIPTION****TORQUE****Steering Column**


Steering Wheel Nut . . . . . 61 N·m (45 ft. lbs.)

Column Bracket Nuts . . . . . 12 N·m (105 in. lbs.)

Shaft Coupler Bolts . . . . . 49 N·m (36 ft. lbs.)

## SPECIAL TOOLS

## STEERING COLUMN

*Puller C-3894-A*